

#### 4.6.4 Change Results Display

- ✓ In the **SETUP** Menu move the cursor on **"MAINT."** and press **"ENTER"**
- ✓ Use the +/- keys to change the screen to **"ResultMenu"**
- ✓ Use the cursor to move to the settings and select your preferred setting with the +/- keys:
  - **Simple Default:** The result screen shows the result according to the selected standard (e.g. for ASTM D6378 the result shows the Pabs, for D5191 the results shows the DVPE). Details are available if you click on **"DETAILS"**.
  - **Detail Default:** Per Default, all results are shown in the detailed mode. Results listed are DVPE, RVP, Ptot, Pgas and Pabs, etc.

